

Selective Deposition: A Materials Supplier's Perspective

ASD • April 2017 - Eindhoven
JM. Girard, Air Liquide Advanced Materials CTO & VP R&D



CREATING
CUSTOMER
VALUE

Design small. **Think big**

- **Diversity of ASD**

- **A Materials Supplier Perspective:**

The balancing act of Innovation vs Manufacturability

- **Illustrative examples of contributions**

- **Highlights**

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



Diversity of ASD


Design small.
Think big

• Selective CVD/ALD

- Selective Epi
- Selective W / Mo (~ 1980) on Si, TiN, Al
- Salicide / selective surface reactions
- « Induction time » in metal CVD
- SAM-based methods

• Topography based methods

- Super conformal catalysed or inhibited CVD
- Flowable
- Dep / Etch / Dep / Etch (« sequential HDP CVD »)



➔ Some may need an (partial) etchback

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



A Materials Supplier Perspective: Contribution

Design small.
Think big

→ Pathfinding / tool kit building

• Precursor design / tuning & rework

- H₂O-based process
- high GPC
- Higher thermal stability precursors (metal CVD)
- Low T precursors (SAM-based ALD)
- Etch / Dep controllable precursors.

• SAM Design & Combinatorial screening

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



Manufacturability Constraints (not ASD specific)

Design small.
Think big

• Safety

- High pace of molecule introduction + extreme property materials
 - 2 major accident / years on average in the last 7 years at precursor suppliers

• Regulatory

- TSCA, REACH, K-REACH, TW-REACH, RoHS, IMDG...
- No self decomposition at 65°C for ~ 1 week with no P buildup / self heating
- Customer specific « banned substance lists »
- Cost of implementation / entry barriers of new substances

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



- **Affordability (lower precursor efficiency in selective CVD)**

- Reuse of molecules « available » from other industries
- # of synthesis steps from closest commodity materials (think of the LIGAND!)
- Yield of each steps

- **Defect Free Manufacturing**

- No « usual suspects » in precursor/SAM impurity effects
- No standard metrology for blocking layer efficiency at early stage
- Acute sensitivity to impurities in intrinsic selective CVD processes



- **SAM design (HT, coverage%,...) for DoM**

- Monopodal SAM screening for DoM ALD
- Chemistry consideration for HT SAMs


- **Ru CVD growth selective inhibition**

- **Metal oxide etch back (selective etch, etch back)**




Area Selective ALD (-OH protection based)

Design small.
Think big




- Nb of attachment legs (1/2/3) & chemical function
- R chain length/ backbone structure
- R chain functionality (-CF₂-, -CH₂-, ...)
- More exotic pods (di-pods for HT applications)


➔ **Highly combinatorial problem** ➔ **need a screening tool**



- Long and narrow tail
- 3 bonding sites



- Short and wide tail
- 1 bonding site




- Short and narrow tail
- 2 bonding sites



AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH


Screening Results example

Design small.
Think big



Screening Results

Design small.
Think big




AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



Challenges

Design small.
Think big


- Metrology of early « nucleation » (\ll DL of XPS)
- Preferential appearance of defects at sharp edges
- Effect of SAM dispense method and exposure (additional variable)



AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



Dipodal Silane Hydrolutic Stability
compared to conventional silane




B. Arkles, et al. Chemistry - A European Journal, 2014, 20, 9442.

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH


Enhanced selectivity CVD: RuCVD

Design small.
Think big





Si



Pt



SiO2



AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



Metal Oxide Dry Etch Back (Thermal, continuous) Design small. Think big

(Å/sec)

F-based	150°C	200°C	300°C	350°C	400°C	425°C
Nb ₂ O ₅	13.5	90.0	185	>330	>330	>330
Ta ₂ O ₅	0	67.7	247	>283	>283	>287
ZrO ₂	0	0	0.46	7.5	~370	>370
HfO ₂	0	0	0	1.9	14.7	E/D
TiO ₂	0	1.7	153	>315	>315	>315
Al ₂ O ₃	0	0	0	0	0	0
SiO ₂	0	0	0	0	0	0
TiN	0	Etched	Etched	Etched	Etched	Etched
TaN	0	0	Etched/Changed	Etched/Changed	Etched/Changed	Etched/Changed
SiN	-	-	0.46	3.8	5.1	12.8

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH



- Energetic & Toxic materials – Stay safe
- Don't stop material innovation, but consider scalability early
- Revisit old data / « failed experiments »
- Defectivity & impurity effects : just the beginning



THANK YOU

AIR LIQUIDE, THE WORLD LEADER IN GASES, TECHNOLOGIES AND SERVICES FOR INDUSTRY AND HEALTH

